

§ 141.531

§ 141.531 What criteria must a State use to determine that a profile is unnecessary?

States may only determine that a system's profile is unnecessary if a system's TTHM and HAA5 levels are below 0.064 mg/L and 0.048 mg/L, respectively. To determine these levels, TTHM and HAA5 samples must be collected after January 1, 1998, during the month with the warmest water temperature, and at the point of maximum residence time in your distribution system.

§ 141.532 How does my system develop a disinfection profile and when must it begin?

A disinfection profile consists of three steps:

- (a) First, your system must collect data for several parameters from the plant as discussed in §141.533 over the course of 12 months. If your system serves between 500 and 9,999 persons you must begin to collect data no later than July 1, 2003. If your system serves fewer than 500 persons you must begin to collect data no later than January 1, 2004.
- (b) Second, your system must use this data to calculate weekly log inactivation as discussed in §§141.534 and 141.535; and
- (c) Third, your system must use these weekly log inactivations to de-

velop a disinfection profile as specified in §141.536.

§ 141.533 What data must my system collect to calculate a disinfection profile?

Your system must monitor the following parameters to determine the total log inactivation using the analytical methods in §141.74 (a), once per week on the same calendar day, over 12 consecutive months:

- (a) The temperature of the disinfected water at each residual disinfectant concentration sampling point during peak hourly flow;
- (b) If your system uses chlorine, the pH of the disinfected water at each residual disinfectant concentration sampling point during peak hourly flow;
- (c) The disinfectant contact time(s) ("T") during peak hourly flow; and
- (d) The residual disinfectant concentration(s) ("C") of the water before or at the first customer and prior to each additional point of disinfection during peak hourly flow.

§ 141.534 How does my system use this data to calculate an inactivation ratio?

Calculate the total inactivation ratio as follows, and multiply the value by 3.0 to determine log inactivation of *Giardia lamblia*:

If your system * * *	Your system must determine * * *
(a) Uses only one point of disinfectant application.	(1) One inactivation ratio (CT _{calc} /CT _{99.9}) before or at the first customer during peak hourly flow or (2) Successive CT _{calc} /CT _{99.9} values, representing sequential inactivation ratios, between the point of disinfectant application and a point before or at the first customer during peak hourly flow. Under this alternative, your system must calculate the total inactivation ratio by determining (CT _{calc} /CT _{99.9}) for each sequence and then adding the (CT _{calc} /CT _{99.9}) values together to determine (3CT _{calc} /CT _{99.9}).
(b) Uses more than one point of disinfectant application before the first customer.	The (CT _{calc} /CT _{99.9}) value of each disinfection segment immediately prior to the next point of disinfectant application, or for the final segment, before or at the first customer, during peak hourly flow using the procedure specified in paragraph (a)(2) of this section.

§ 141.535 What if my system uses chloramines, ozone, or chlorine dioxide for primary disinfection?

If your system uses chloramines, ozone, or chlorine dioxide for primary disinfection, you must also calculate the logs of inactivation for viruses and develop an additional disinfection profile for viruses using methods approved by the State.

§ 141.536 My system has developed an inactivation ratio; what must we do now?

Each log inactivation serves as a data point in your disinfection profile. Your system will have obtained 52 measurements (one for every week of the year). This will allow your system and the State the opportunity to evaluate how microbial inactivation varied over the course of the year by looking

Environmental Protection Agency

§ 141.550

at all 52 measurements (your Disinfection Profile). Your system must retain the Disinfection Profile data in graphic form, such as a spreadsheet, which must be available for review by the State as part of a sanitary survey. Your system must use this data to calculate a benchmark if you are considering changes to disinfection practices.

DISINFECTION BENCHMARK

§ 141.540 Who has to develop a disinfection benchmark?

If you are a subpart H system required to develop a disinfection profile under §§141.530 through 141.536, your system must develop a Disinfection Benchmark if you decide to make a significant change to your disinfection practice. Your system must consult with the State for approval before you can implement a significant disinfection practice change.

§ 141.541 What are significant changes to disinfection practice?

Significant changes to disinfection practice include:

- (a) Changes to the point of disinfection;
- (b) Changes to the disinfectant(s) used in the treatment plant;
- (c) Changes to the disinfection process; or
- (d) Any other modification identified by the State.

§ 141.542 What must my system do if we are considering a significant change to disinfection practices?

If your system is considering a significant change to its disinfection practice, your system must calculate a disinfection benchmark(s) as described in §§141.543 and 141.544 and provide the benchmark(s) to your State. Your system may only make a significant disinfection practice change after consulting with the State for approval. Your system must submit the following information to the State as part of the consultation and approval process:

- (a) A description of the proposed change;
- (b) The disinfection profile for *Giardia lamblia* (and, if necessary, viruses) and disinfection benchmark;
- (c) An analysis of how the proposed change will affect the current levels of disinfection; and
- (d) Any additional information requested by the State.

§ 141.543 How is the disinfection benchmark calculated?

If your system is making a significant change to its disinfection practice, it must calculate a disinfection benchmark using the procedure specified in the following table.

To calculate a disinfection benchmark your system must perform the following steps

Step 1: Using the data your system collected to develop the Disinfection Profile, determine the average *Giardia lamblia* inactivation for each calendar month by dividing the sum of all *Giardia lamblia* inactivations for that month by the number of values calculated for that month.

Step 2: Determine the lowest monthly average value out of the twelve values. This value becomes the disinfection benchmark.

§ 141.544 What if my system uses chloramines, ozone, or chlorine dioxide for primary disinfection?

If your system uses chloramines, ozone or chlorine dioxide for primary disinfection your system must calculate the disinfection benchmark from the data your system collected for viruses to develop the disinfection profile in addition to the *Giardia lamblia* disinfection benchmark calculated under §141.543. This viral benchmark must be calculated in the same manner used to calculate the

Giardia lamblia disinfection benchmark in §141.543.

COMBINED FILTER EFFLUENT REQUIREMENTS

§ 141.550 Is my system required to meet subpart T combined filter effluent turbidity limits?

All subpart H systems which serve populations fewer than 10,000, are required to filter, and utilize filtration other than slow sand filtration or diatomaceous earth filtration must meet the combined filter effluent turbidity